

## Curing times

### FIS V Zero

#### Temperature at anchoring base

[°C]	Maximum processing time $t_{work}$		Minimum curing time <sup>1)</sup> $t_{cure}$	
	[hrs.]	[min.]	[hrs.]	[min.]
-10 - -5 <sup>2)</sup>	6	-	72	-
> -5 - 0 <sup>2)</sup>	2	-	24	-
> 0 - +5 <sup>2)</sup>	-	45	12	-
> +5 - +10	-	20	6	-
> +10 - +15	-	8	3	-
> +15 - +20	-	5	2	-
> +20 - +25	-	3	1	-
> +25 - +30	-	2	-	45
> +30 - +40	-	1	-	30

1) In wet concrete or water-filled holes the curing times must be doubled.

2) Minimum cartridge temperature +5 °C.